

Installation of METSIM® Software and USB Key Driver:

1. Download the key driver from www.metsim.com/pub/USBKeyDriver.zip, or for the latest Windows 10 versions, www.metsim.com/pub/USBKeyDriverWin10.zip
2. Run USBKeyDriver.exe
 - IMPORTANT: When prompted to allow Sentinel Safenet to adjust network security settings for this computer, 'Yes' must be selected. If 'No' is selected, the computer will block all other network computers from accessing the key.
3. Download METSIM® from www.metsim.com/pub/METSIMLATEST.zip
4. Run METSIM.exe application to install METSIM®
5. Restart the computer

Black Network Keys:

1. From the C/METSIM directory, open the sntlconfig.xml file using Notepad or Wordpad
2. Between the two lines <ContactServer>, enter the server/computer name or ip address where the black key is plugged in; save this file upon closing;
3. METSIM® may be started from the Program list or by double-clicking the METSIM.application file located in C/METSIM;
4. Repeat steps 1-5 from above for installing METSIM®; repeat these steps 1-3 for all computers running METSIM

IMPORTANT: ALL STEPS ABOVE MUST BE FOLLOWED EXACTLY AND ALL STEPS MUST BE REPEATED FOR ALL COMPUTERS ACCESSING METSIM®.